

VOR RWY 34
QUONSET STATE (OQU)

MISSED APPROACH: Climbing right turn to 1800 on PVD
VOR/DME R-186 to BRUCE INT/PVD 13.2 DME and hold.

FAF to MAP 5.2 NM					
Knots	60	90	120	150	180
Min:Sec	5:12	3:28	2:36	2:05	1:44