

RNAV (RNP) Z RWY 19
TETERBORO (TEB)

COATE (RNP 0.30)

Procedure NA for arrivals at COATE on T218, V116-188 northwest bound and V252 northbound.

3000 127° (14.3)

3000 095° (21)

STILLWATER STW (RNP 0.30)

3000 095° (12)

(IAF) LELME

3000 036° (11.1)

SHOTT

3000 044° (20)

SOLBERG SBJ (RNP 0.30)

ELEV 8 TDZE 6

Procedure NA for arrivals on SBJ VOR/DME airway radials 028 CW 117.

1500 FOXIB 3000 MORN

tr 306°

COMOK

HOOH

ALSIV

JAPIR

1500 1500

195° 180°

2000 3000

GP 3.00° TCH 54

CATEGORY	A	B	C	D
RNP 0.10 DA	499-1 $\frac{3}{4}$	493 (500-1 $\frac{3}{4}$)		

AUTHORIZATION REQUIRED

NE-2, 03 DEC 2020 to 31 DEC 2020