

VOR/DME CVO 115.4 Chan 101	APP CRS 252°	Rwy Idg TDZE Apt Elev	N/A N/A 250
--	------------------------	-----------------------------	--

VOR-A
CORVALLIS MUNI (CVO)

<p>When local altimeter setting not received, procedure NA.</p>	<p>MISSED APPROACH: Climbing left turn to 3000 on CVO VOR/DME R-081 to SHEDD INT/EUG 22.1 DME and hold, continue climb-in-hold to 3000.</p>
---	---

AWOS-3PT 135.775	CASCADE APP CON ★ 127.5 348.7	UNICOM 123.075 (CTAF) ①
----------------------------	---	-----------------------------------

