

VORTAC GGG <b>112.9</b> Chan <b>76</b>	APP CRS <b>125°</b>	Rwy Idg TDZE <b>358</b> Apt Elev <b>365</b>
--	------------------------	---

VOR/DME or TACAN RWY 13  
EAST TEXAS RGNL (GGG)

▼ For inoperative MALSRS, increase S-13 Cat E visibility to 1¾. When local altimeter setting not received, use Gilmer altimeter setting and increase all MDA 60 feet and visibility ▲ Cat D and E ¼ mile. VDP NA when using Gilmer altimeter setting. For inoperative MALSRS when using Gilmer altimeter setting increase S-13 Cat E visibility to 2 miles.	MALSRS AS	MISSED APPROACH: Climb to 3000 via GGG R-126 to ARGEN Int/GGG 14 DME and hold.
--	--------------	---

ATIS <b>119.65</b>	LONGVIEW APP CON * <b>128.75 379.15</b>	EASTEX TOWER * <b>119.2 (CTAF) 377.05</b>	GND CON <b>121.6</b>	UNICOM <b>122.95</b>
-----------------------	--	--	-------------------------	-------------------------

