



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 4, 8, 14, 22, 26*32: Climbing via assigned heading, thence radar vectors to assigned departure fix. Cross 10 DME at or above 10,000, cross departure fix as assigned by ATC.

LOST COMMUNICATIONS/NON-RADAR

If radar vectors are not received or available by NQX TACAN 8 DME, climb to 12,000, fly assigned departure heading to intercept NQX 10 DME arc. Arc to respective departure radial, then via departure radial to assigned departure fix.
Do not ARC northeast of NQX TACAN between R-035 clockwise to R-084.