

RNAV (GPS) RWY 18
ORLANDO SANFORD INTL (SFB)

MISSED APPROACH: Climb to 600 then climbing left turn to 2100 direct GOPCE and hold.

Procedure NA for arrivals at WORMS on V267 northbound.

(IAF) WORMS Δ 1549

2000 116° (8.2)

(IF) GOPCE Δ 1740

185° 1600 (6.1)

(FAF) ZUBAV

271 Δ 165

RW18 Δ 192

339 Δ

(IAF) DIGGR

2000 218° (6.6)

4 NM

005°

Procedure NA for arrivals at SMYRA on V3-533 southbound.

(IAF) SMYRA

2000 264° (13)

MSA RW18 25 NM

2800

ELEV 55	D TDZE 49
185° to RW18	

ELEV 55

TDZE 49

185° to RW18

16 8 27R 36 27L

11002 X 1501

3578 X 75

11002 X 27C

11001 X 150

5839 X 75

0.4% UP

0.4% UP

MRL 16, 8, 27R, 36, 27L

HIRL 16, 8, 27R, 36, 27L

REIL Rwy 9C, 18, 27L and 36

SE-3, 03 DEC 2020 to 31 DEC 2020