

VORTAC ODI <b>117.9</b> Chan <b>126</b>	APP CRS <b>184°</b>	Rwy Idg TDZE Apt Elev <b>1179</b>	<b>N/A</b> <b>N/A</b> <b>1179</b>
▲ NA Use La Crosse, WI altimeter setting. Procedure NA at night.		MISSED APPROACH: Climb to 2800 then left turn via ODI R-184 to AUTOS/14 DME and hold.	
MINNEAPOLIS CENTER <b>128.6 363.0</b>		CTAF <b>122.9 0</b>	

