

VOR-A
LEHIGH VALLEY INTL (ABE)

MISSED APPROACH: Climbing right turn to 3000 direct ETX VOR/DME and hold.

DME or RADAR REQUIRED

