

OXNARD, CALIFORNIA

POINT MUGU
Chan 43 NTD ≡ ∴

TACAN REQUIRED

DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 3: Climbing left turn to 212° within 3 DME of NTD TACAN, thence...

TAKE-OFF RWY 21: Turn right, thence...

TAKE-OFF RWY 27: Turn left, thence...

Intercept NTD R-248 and via NTD R-248 to FANKO (NTD R-248/16 DME), then via RZS VORTAC R-133 to RZS VORTAC, then via assigned routing.
Cross CIBCI (RZS R-133/17 DME) at or above 5700.

AVENAL TRANSITION (RZS 1•AVE): From over SAN MARCUS VORTAC via RZS R-335 to AVENAL VOR/DME. Cross SAN MARCUS VORTAC at or above 7900.

SHAFTER TRANSITION (RZS 1 •EHF): From over SAN MARCUS VORTAC via RZS R-016 to SHAFTER VORTAC. Cross SAN MARCUS VORTAC at or above 8900.

POINT MUGU NAS (NAVAL BASE VENTURA CO) (KNTD)