

<div>T</div>	<div>DEPARTURE ROUTE DESCRIPTION</div> <div>When entering controlled airspace, fly assigned heading and altitude, for vector to appropriate route.</div> <div><div>ARDMORE TRANSITION (TEX8.ADM): From over FUZ VORTAC on FUZ R-348 to LOWGN, then on ADM R-179 to ADM VORTAC.</div><div>BLECO TRANSITION (TEX8.BLECO): From over FUZ VORTAC on FUZ R-360 to BLECO.</div><div>DECKK TRANSITION (TEX8.DECKK): From over FUZ VORTAC on FUZ R-360 to NOOGY, then on IRW R-144 to DECKK.</div><div>EAKER TRANSITION (TEX8.EAKER): From over FUZ VORTAC on FUZ R-012 to EAKER.</div><div>GRABE TRANSITION (TEX8.GRABE): From over FUZ VORTAC on FUZ R-012 to GRABE.</div><div>OKMULGEE TRANSITION (TEX8.OKM): From over FUZ VORTAC on FUZ R-012 to EAKER, then on OKM R-196 to OKM VOR/DME.</div><div>ROLLS TRANSITION (TEX8.ROLLS): From over FUZ VORTAC on FUZ R-348 to LOWGN, then on ADM R-179 to ADM VORTAC, then on ADM R-303 to ROLLS.</div><div>TULSA TRANSITION (TEX8.TUL): From over FUZ VORTAC on FUZ R-360 to ZEMMA, then on TUL R-201 to TUL VORTAC.</div><div>WILL ROGERS TRANSITION (TEX8.IRW): From over FUZ VORTAC on FUZ R-360 to ZEMMA, then on IRW R-145 to IRW VORTAC.</div><div>ZEMMA TRANSITION (TEX8.ZEMMA): From over FUZ VORTAC on FUZ R-360 to ZEMMA.</div></div> <div><div>NOTE: BLECO TRANSITION: ATC assigned.</div><div>NOTE: DECKK TRANSITION: For all aircraft inbound to the Oklahoma City area.</div><div>NOTE: EAKER TRANSITION: For aircraft inbound to the Tulsa terminal area.</div><div>NOTE: GRABE TRANSITION: ATC assigned.</div><div>NOTE: OKMULGEE TRANSITION: For all aircraft overflying OKM VOR/DME proceeding on J181 to BDF to destinations in the Chicago terminal area and north.</div><div>NOTE: ROLLS TRANSITION: For all aircraft proceeding northwest bound on J52.</div><div>NOTE: TULSA TRANSITION: For all aircraft overflying TUL VORTAC.</div><div>NOTE: WILL ROGERS TRANSITION: For all aircraft overflying IRW VORTAC.</div></div>
--------------	---