

| ▼ | DEPARTURE ROUTE DESCRIPTION |
|---|--|
| | <p><u>TAKEOFF RUNWAY 3:</u> Climb to assigned altitude and heading between 350° CW 150° from DER, Thence. . . .</p> <p><u>TAKEOFF RUNWAYS 12L/R:</u> Climb to assigned altitude and heading between 150° CCW 350° from DER. Thence. . . .</p> <p><u>TAKEOFF RUNWAY 21:</u> Climbing left turn to assigned altitude and heading between 150° CCW to 024° from DER. Thence. . . .</p> <p><u>TAKEOFF RUNWAYS 30L/R:</u> Climbing right turn to assigned altitude and heading between 350° CW 113° from DER. Thence. . . .</p> <p>. . . .RADAR vectors to assigned route. Expect filed altitude 10 minutes after departure.</p> <p><u>LOST COMMUNICATIONS:</u> If no transmissions are received within one minute after departure, maintain assigned heading until 7000 feet, then climb to filed altitude via direct DEN VOR/DME, thence via assigned transition. If filed altitude is above 10000 feet, cross DEN VOR/DME at or above 11000 feet.</p> <p><u>AKRON TRANSITION (PLAIN1.AKO):</u> From over DEN VOR/DME on DEN R-065 and AKO R-241 to AKO VOR/DME.</p> <p><u>ASHBY TRANSITION (PLAIN1.ASHBY):</u> From over DEN VOR/DME on DEN R-065 and AKO R-241 to AKO VOR/DME, then on AKO R-066 and HCT R-250 to ASHBY.</p> <p><u>BELKE TRANSITION (PLAIN1.BELKE):</u> From over DEN VOR/DME on DEN R-076 and MCK R-253 to BELKE INT.</p> <p><u>CABET TRANSITION (PLAIN1.CABET):</u> From over DEN VOR/DME on DEN R-087 and TXC R-264 to TXC VORTAC, then on TXC R-084 to CABET.</p> <p><u>GARDEN CITY TRANSITION (PLAIN1.GCK):</u> From over DEN VOR/DME on DEN R-100 and GCK R-309 to GCK VORTAC.</p> <p><u>GOODLAND TRANSITION (PLAIN1.GLD):</u> From over DEN VOR/DME on DEN R-087 and TXC R-264 to TXC VORTAC, then on TXC R-092 and GLD R-273 to GLD VORTAC.</p> <p><u>HAYES CENTER TRANSITION (PLAIN1.HCT):</u> From over DEN VOR/DME on DEN R-065 and AKO R-241 to AKO VOR/DME, then on AKO R-066 and HCT R-250 to HCT VORTAC.</p> <p><u>MCCOOK TRANSITION (PLAIN1.MCK):</u> From over DEN VOR/DME on DEN R-076 to TEKMY, then on MCK R-253 to MCK VOR/DME.</p> <p><u>THURMAN TRANSITION (PLAIN1.TXC):</u> From over DEN VOR/DME on DEN R-087 and TXC R-264 to TXC VORTAC.</p> <p><u>WEEDS TRANSITION (PLAIN1.WEEDS):</u> From over DEN VOR/DME on DEN R-100 to WEEDS.</p> |