

|             |         |          |     |
|-------------|---------|----------|-----|
| VOR/DME GEE | APP CRS | Rwy Idg  | N/A |
| 108.2       | 085°    | TDZE     | N/A |
| Chan 19     |         | Apt Elev | 814 |

VOR-A


CANANDAIGUA (IUA)

NA

DME or RADAR required.

MISSED APPROACH: Climb to 2000 then climbing right turn to 3000 direct GEE VOR/DME and hold.

|                    |                                   |                          |
|--------------------|-----------------------------------|--------------------------|
| AWOS-3P<br>118.675 | ROCHESTER APP CON<br>119.55 269.6 | UNICOM<br>122.8 (CTAF) 0 |
|--------------------|-----------------------------------|--------------------------|



One Minute Holding Pattern

GEE VOR/DME

SECKY GEE (13.5) RADAR

WIVRI GEE (17)

ZUDUT GEE (18.5)

2000

3000

GEE

3000

2800

1580

13.5 NM

3.5 NM

1.5 NM

CATEGORY

A

B

C

D

CIRCLING

1580-1  
766 (800-1)

1580-1¼  
766 (800-1¼)

1580-2¼  
766 (800-2¼)

NA

WIVRI FIX MINIMUMS

1500-1  
686 (700-1)

1540-2  
726 (800-2)

NA

FAF to MAP 5 NM

Knots

60

90

120

150

180

Min:Sec

5:00

3:20

2:30

2:00

1:40

ELEV 814

0.4% UP

5500 X 100

085° 5 NM from FAF