

LOC I-JOU <b>111.1</b>	APP CRS <b>210°</b>	Rwy Idg <b>8999</b> TDZE <b>1430</b> Apt Elev <b>1430</b>
---------------------------	------------------------	---

ILS or LOC RWY 21

JOE FOSS FIELD (FSD)

⚠

ASR

-31°C

For inoperative MALSR increase S-ILS all Cats visibility to ¾ mile,  
increase S-LOC 21 Cat C/D visibility to 1⅞ mile. When using  
WADRI FIX minimums, increase S-LOC 21 Cat C/D visibility to 1 mile.

MALSR

MISSED APPROACH: Climb to 3400  
then right turn direct FSD VORTAC  
and hold.

ATIS <b>126.6</b>	SIoux FALLS APP CON ★ <b>125.8 284.725</b>	SIoux FALLS TOWER ★ <b>118.3 (CTAF) 0 257.8</b>	GND CON <b>121.9 348.6</b>	UNICOM <b>122.95</b>
----------------------	---	--	-------------------------------	-------------------------

SIoux FALLS 115.0 FSD Chan 97

LOCALIZER 111.1 I-JOU

WADRI INT FSD 3.6

JOESY OM/INT

LEYIN INT

(IAF) SECTO FSD 15.3

3100 NoPT 226° (4.8)

3100 210° (6.7)

R-074

R-327

R-110

1939

1847

1603

1627

1697

1658

1800

3445

1961

MSA FSD 25 NM

3300

4500

ELEV 1430	D	TDZE 1430	3400	FSD	JOESY OM/INT	One Minute Holding Pattern	
210° 4.9 NM from FAF		*LOC only.		WADRI INT FSD 3.6	3047		
S1		2100*		030°		3100	
1523		2 NM		2.9 NM		GS 3.00° TCH 49	
8999 X 130		CATEGORY		A	B	C	D
8000 X 130		S-ILS 21		1630/18 200 (200-½)			
3148 X 75		S-LOC 21		2100/24 670 (700-½)		2100-1½ 670 (700-1½)	
1470		CIRCLING		2100-1 670 (700-1)		2100-1¾ 670 (700-1¾)	
AS		WADRI FIX MINIMUMS		2200-2½ 770 (800-2½)			
TDZ/CL Rwy 21		S-LOC 21		1800/24 370 (400-½)		1800/35 370 (400-¾)	
REIL Rwys 15 and 33		CIRCLING		1960-1 530 (600-1)		2060-1¾ 630 (700-1¾)	
MIRL Rwy 9-27				1980-1 550 (600-1)		2200-2½ 770 (800-2½)	
HIRL Rwys 3-21 and 15-33							
FAF to MAP 4.9 NM							
Knots	60	90	120	150	180		
Min:Sec	4:54	3:16	2:27	1:58	1:38		

SIoux FALLS, SOUTH DAKOTA

Amdt 10C 18JUN20

43°35'N-96°45'W

JOE FOSS FIELD (FSD)

ILS or LOC RWY 21